

# Iridium Extreme PTT Push-To-Talk Mode Quick Guide

## Getting Started

### Calling From the Satellite Phone in Phone Mode

- To call a landline/cell phone, dial : **00 > Country Code > Area Code > Phone Number**  
*For example : 00 1 941 955 1020 (Do not include dashes or spaces)*
- To call satellite phone to satellite phone, dial : **00 > Satellite Phone Number**  
*For example : 00 8816 1234 5678 (Do not include dashes or spaces)*

### **\*Follow these steps to enter PTT Mode if your Iridium Extreme PTT device is in Phone Mode:**

1. Press the **left soft key**, labeled **Menu**.
2. Press the **left soft key**, labeled **Select > Switch to PTT**. The transition to PTT Mode takes approximately 10 seconds. **"Waiting for Registration"** is displayed on the device after the switch to PTT. To switch back to phone mode, go back to **Menu** and select **Switch to Phone**.

**\*\*\* A "PTT" designation will appear at the top center of the screen when the transition is complete and the device will identify your Home Talkgroup at the bottom of your screen. \*\*\***

**\*\*\* If your Home Talkgroup is active when you switch to PTT Mode, your device will enter the talkgroup automatically and the screen will display the LISTENING or OPEN status. \*\*\***

### Navigating to Phone Mode to Dial

\*If you attempt to dial a phone number while in Push-To-Talk mode, you will receive the following notification: "Dialing not supported. Must go to Phone mode to dial".

1. Press the **left soft key**, labeled **Phone** to switch to Phone Mode. As you are transitioning, you will be prompted to "Dial number again when in Phone Mode".
2. If you want to remain in PTT Mode, press the **right soft key**, labeled **Back** to return to the previous screen.

### Using SOS

\*If you attempt to press the SOS button while in PTT Mode, you will receive the following notification: **"WARNING! Must go to Phone Mode for SOS."**

1. Press the **left soft key**, labeled **Phone**, to switch to Phone Mode. While transitioning, you will be prompted to "Press SOS again when in Phone Mode". You must press the SOS button again in Phone Mode to successfully initiate an SOS call.

### LISTENING

\*Your device displays LISTENING when the monitored talkgroup is active, but you are not the one talking.

### TALKING

\*To talk on a talkgroup, you must first ensure that you have selected the correct talkgroup as your Home Talkgroup.

1. Push the PTT Button and wait for the *Talk Tone* (three notes ascending in rapid succession) before speaking. If you are granted the floor and are allowed to talk, your handset displays TALKING and listeners see LISTENING. When you are the one talking to the talkgroup, TALKING is displayed on the screen.
2. When TALKING is displayed, the PTT Button is held down and other keys are disabled during use. The device cannot perform other functions until the PTT Button is released.

**\*\*\*You may hold the floor and communicate with the talkgroup for a maximum of 20 seconds per PTT Button press. If you have configured your device with Talk Timer Enabled, the time remaining to speak in the current talk period is displayed on the screen below the Device Name.\*\*\***

### OPEN

\*When the talkgroup is active but no one is talking, the screen displays OPEN. This indicates that the floor is available and that participants may request the floor by pushing and holding the **PTT Button**.

### Talkgroups List

\*To change the talkgroup being monitored in Home Mode, navigate to the Talkgroups List screen from the Home State (or the Scan State when no talkgroups are active).

\* The currently monitored talkgroup is highlighted by two side arrows and the Priority Talkgroup, if defined for the device, is denoted by "!" marks on either side and highlighted by white text on a black background.

1. To change the Home Talkgroup, navigate to the desired talkgroup and select "Join".

### Talkgroups terms

- **Priority Talkgroup** - Displayed as white lettering on a black background and exclamation points on either side.
- **Home Talkgroup** - Represented by arrows on either side of the Talkgroup. Stays with Home Talkgroup as user scrolls.
- **Cursor / Focus** - The highlighted talkgroup appears in a frame. Cursor line is always in the middle of the screen.
- **Active Talkgroups** - Represented by the active talkgroup names flashing.

**PTT Mode Terms**

**Floor** - When a PTT user has been given access to communicate with the other devices in the talkgroup.

**Home State** - Allows you to listen to activity on one talkgroup.

**IDLE** - When a talkgroup is not active in the network, the devices that have the talkgroup as their Home Talkgroup will display IDLE.

**Out of Talkgroup Area** - Displayed on the device when the user pushes the PTT Button but is out of the talkgroup's defined area at the time.

**Priority Talkgroup** - Each Iridium PTT device may have one of its talkgroups identified as its priority talkgroup. This priority talkgroup will take precedence for communication over other talkgroups provisioned for the device.

**Scan State** - Allows you to listen for activity on any of the talkgroups for which your device is provisioned.

**SCANNING** - When the device is in the Scan State.

**Waiting for Activity** - When an Iridium PTT device is in Scan State and none of the device's talkgroups are active, "Waiting for Activity" is shown on the screen.

**Thank you for choosing [SatellitePhoneStore.com!](http://SatellitePhoneStore.com)**

**\*\*\*PLEASE RECYCLE & RETURN BOOKLET WITH YOUR RENTAL TO OUR OFFICE AFTER USE\*\*\***

**RETURN YOUR RENTAL :**

Satellite Phone Store  
Attn: Rental Returns

*Florida Office*  
1414 S. Tamiami Trail  
Sarasota, FL 34239 USA

*Alaska Office*  
1231 West Northern Lights Blvd, Ste. 202  
Anchorage, Alaska 99503 USA

*California Office*  
2830 Shelter Island Dr.  
San Diego, CA 92106



**Iridium Extreme PTT Push-To-Talk Mode Quick Guide**

**Please note that you MUST make a test call, 1.480.752.5105, on your phone before leaving on your trip!**

