

For Windows XP SP2, 3:

1. Install the USB driver from the included Iridium Data CD, follow the instructions on the CD.
2. Download Iridium's Direct Internet 2.0 from :
[Iridium Direct Internet 2.0.2 - Complete Download -](#)
3. Run Direct Internet 2.0, note that must read instructions on installing generic 19200 driver.
4. Once installation complete you will have a dialup connections labeled Direct Internet 2.0. Whenever you want to use the Connection double-click on that connection and select "Dial"
* The connection is found under Control Panel > Network Connections, you can also create a shortcut and place it on your desktop.

For Windows Vista: (Direct Internet 2.0 won't work on Windows Vista)

During any of the following steps you may be required several times to approve access by Windows User Account Control (UAC). When prompted, choose *Continue*.

Install the Modem

1. Close all applications.
2. Choose *Start > Control Panel*.
3. Double click on *Phone and Modem Options*.
4. Select the *Modems* tab and click *Add*.
5. Check *Don't detect my modem; I will select it from a list*. Then, click *Next >*.
6. From the Manufacturer list, highlight *Standard Modem Types*
7. In the right pane click *Standard 19200bps Modem*, and then click *Next>*.
8. Click the Selected ports button. Click on an available COM Port (e.g., COM 3). This is the port to which you will connect your Iridium device. Click *Next >*.
9. Click *Finish*. Close all windows except Control Panel.
10. Modem addition and setup complete. *Close the Phone and Modem Options window*.

Configure Dial-Up Networking

1. Choose *Start > Control Panel* Double Click on *Network and Sharing Center*.
2. Click *Set Up a Connection or Network* (upper left).
3. Choose *Set Up a Dial Up Connection*. Click *Next>*.
4. In the *Dial Up Phone Number* field, type: **008816000025**
5. Leave *User Name and Password* fields blank, In the *Connection Name* field create an appropriate name for the connection (e.g. Iridium Data).
6. Click *Connect* then *Skip* and choose *Set Up The Connection Anyway*. Click *Close*.
7. Return to the *Network and Sharing Center* and choose *Manage Network Connections* (upper left) to initiate call dialing.

Dialing a Call

To place a PPP Data call, you must open the Dial-Up Networking window and select the dial-up connection you created for your Iridium phone.

1. Connect the computer and phone.
2. Orient the phone's antenna with a clear view of the sky.
3. If your computer is turned off, turn it on and wait for it to boot up.
4. Turn on your Iridium phone and wait for it to register with the satellite network.
5. Depending on your Windows operating system, choose one of the following to open the Dial-Up Networking window:
 - a. *Start > Programs > Accessories > Dial-Up Networking*
 - b. *Start > Programs > Accessories > Communications > Dial-Up Networking*
 - c. *Start > Programs > Accessories > Communications > Network and Dial-up Connections*
 - d. *Start > All Programs > Accessories > Communications > Network Connections*
 - e. *Start > Connect To > Select Connection Name*