



Iridium Satellite Voice Mail Instructions

29 July 2008

Voicemail Set-up Instructions:

1. Go outside with a clear view of the sky.
2. Turn phone on, wait for registration.
3. Push the MENU button
4. Scroll down to CALL RELATED FEATURES press "ok"
5. Scroll to CALL FOWARDING press "ok"
6. Scroll to FORWARDING WHEN UNAVAILABLE press "ok"
7. Please wait...
8. Make sure the check mark is set to "ON" then press "ok"

YOUR VOICEMAIL SETUP SHOULD NOW BE COMPLETE

If the screen displays “try again”, the signal was not strong enough for the download, try again in a few minutes or when signal improves.

To Retrieve Voicemail on your Iridium Satellite Phone:

Press the envelope button on the Satellite Phone or
Dial 00 + your 12 digit satellite phone number (MSISDN)

Listen to the instructions carefully. The greeting may ask you to enter the satellite number you would like to leave a message for, dial the 12 digit satellite number. While the voicemail greeting plays, press the * key.
Your Voicemail password will be the LAST SEVEN digits of your satellite phone number.