



## KYOCERA QUICK REFERENCE GUIDE

ENTERING PUK (Pin unblocking KEY) CODE-	Enter PUK code Press [OK]. Enter in your new PIN code. Enter your PIN code again.
FORCE REGISTERING-	Press [MENU], Scroll to [SERVICES], Press [OK], scroll to [REGISTRATION], Press [OK]
ADJUST RINGER VOLUME-	Press [MENU], Scroll to [SETTINGS], Press [OK], scroll to [RINGER], Press [OK], scroll to [RINGER VOLUME], Press [OK], select desired volume, Press [OK]
ADJUST EARPIECE VOLUME-	Press [MENU], scroll to [SETTINGS], Press [OK], scroll to volume, Press [OK], select volume
CALL FORWARDING -ON/OFF-	Press [MENU], scroll to [SERVICES], Press [OK], scroll to forwarding, Press [OK], select a forwarding option, set [ON/OFF] options, Press [OK], Enter the destination # to which calls are to be forwarded (when ON is selected) Press [OK], select time period which calls are to be forwarded (when [NO ANSWER], or [ALL CONDITION] is selected) Press [OK]
CALL BARRING-	Press [MENU], scroll to [SERVICES], scroll to [BARRING], Press [OK], select incoming or outgoing, Press [OK], select a barring option, Press [OK], Enter your password, (default 0000) Press [OK]
CHANGING PIN NUMBER-	Press [MENU], scroll to [SECURITY], Press [OK], scroll to [NEW PIN1], Press [OK], Enter old PIN #, Press [OK], Enter new PIN #, Press [OK], Enter new PIN # again, Press [OK]
TURN PIN NUMBER ON/OFF-	Press [MENU], scroll to [SECURITY], Press [OK], scroll to [PIN1 ON/OFF], Press [OK], Set [ON/OFF] option, Press [OK], Enter [PIN], Press [OK]
CHANGE LANGUAGE-	Press [MENU], scroll to [SETTINGS], Press [OK], scroll to [LANGUAGE], Press [OK], select language, Press [OK]
READ MESSAGES-	Press [MENU], scroll to [MESSAGES], Press [OK], select desired message option
MUTING A CALL ON/OFF-	Press [MENU], scroll to mute, Press [OK]
LOCKING KEYPAD-	Press [MENU], scroll to [SECURITY], Press [OK], scroll to [KEYLOCK], Press [OK], scroll to [KEYLOCK ON], Press [OK]
UNLOCKING KEYPAD-	Press the [C] button in lower left corner twice + the [MEMO] button in the lower right corner