

## RETURN YOUR RENTAL

Satellite Phone Store

Attn: Rental Returns

### 4 LOCATIONS WORLDWIDE

#### Satellite Phone Store

##### Alaska

751 E 36th Ave #105  
Anchorage, AK 99503

#### Satellite Phone Store

##### California

2830 Shelter Island Dr.  
San Diego, CA 92106

#### Satellite Phone Store

##### Ensenada

Calle Riveroll #885  
Local C Zona Centro, Ensenada B.C.

#### Satellite Phone Store

##### Florida

7430 N Tamiami Trail  
Sarasota, FL 34243



# Satellite

PhoneStore.com

1.877.943.6383

## Globalstar GSP-1700

### HOW TO USE YOUR SATELLITE PHONE

QUICK GUIDE

*Thank you for choosing  
Satellite Phone Store!*


## ▶ GETTING STARTED

### Power the phone on/off

Press and hold the end/power key until phone screen turns on.

Wait about 30 seconds and check your screen for service bars and a red house.

When you see these 2 icons on the screen, your phone is registered with the Globalstar Satellite network and you can make a phone call.




### Looking for signal

1. Go outside to an area with a clear view of the sky. Nearby obstructions such as tall buildings, trees or mountains, can prevent calls.

2. Rotate and fully extend the antenna, pointing towards the sky. Turn on your phone by pressing and holding the end/power key.

\*\*\*If the symbol, ▲ is displayed you are Roaming and have to use international (+) dialing.\*\*\*



## ▶ DIALING

1. Dial the **Country code > Area code**

*For example: 1-866-651-7768*

Then press the **send key**

## ▶ ONE-TOUCH DIALING

If one-touch dialing is set to "on", dial any of the 99 location numbers without pressing the send key.

### To one-touch dial a location number

1. Set one-touch dial to "on"

1a. From standby mode, press the left smart-key button for Menu.

1b. Press for Preferences.

1c. Press for Calling

1d. Press for One-Touch Dial

1e. Press or to select "yes".

Press again to select "no".

1f. Press left smart-key button for Ok.

2. Press and hold the location number.

## ▶ VIEW TEXT OR VOICE MESSAGES

1. Press and hold

2. Press or

3. Press to View.

4. Press to go Next

## ▶ DISPLAY INDICATORS

SYMBOL	MEANING
	Indicates signal strength ranging from a strong signal (four lines) to an extremely weak signal (one line)
	Call in progress
	No service available. If service is unavailable, the phone sounds a beep when you try to make a call
	Roaming – Service is established outside the home area
	Home – Service is established inside the home area
	Notification of a text message (not available in all markets)
	Notification of a voice mail message
	Battery charge. Ranges from four vertical bars (full charge), to one bar (minimal charge), to no bars and blinking (no charge)
	Ringer volume indicator
	Ringer silenced
	Indicates that encryption is turned on
	Designates the menu option currently selected
	Indicates that you can scroll between screens using the volume buttons (located on the side of the phone) or the  and  keys
	Indicates that either the selected text message is locked or the keypad is locked
	Indicates that the text message is unlocked